


Water Quality Parameters (WQP) Instructions and Checklist

Where are you?



Verify your WQP monitoring period.

Identify your Entry and Distribution points for WQP Sampling.

Collect samples and Field Data.

Fill out TCEQ form 20679

Send/Ship sample bottles, form 20679, invoice and reporting information to the lab.

Lab's Shipping address: **Eastex Environmental Laboratory**

35 Eastex Lane, Coldspring Tx 77331

Eastex Lab will pick up, at no cost, samples in East Texas/Houston area. Call 936-653-3249 to schedule a pick-up.

You have received your analytical report from the laboratory. (If not, call the lab).

Eastex Lab has submitted your data electronically to TCEQ in the required format.

Check your report.

Evaluate your WQP data for corrosivity and implement your plan.

WQP? Texas,

we got this!

*To make it as painless
as possible, we put a
kit together for you!*